


Installing Stainless Steel Glass Adapter

Overview¹

These instructions will provide step-by-step installation guidelines for installing the Stainless Steel Glass Adapter. The adapter is designed to work with 1/2" (12mm) or 3/8" (9.53mm) glass thickness.

Caution:

Wear protective ANSI approved safety glasses, working gloves and breathing mask at all times.




Tools Required

- 1) Drilling tool to go into wood/concrete
- 2) Appropriate attachment bolts with the connecting surface
- 2) Glass Adapter Tool
- 3) Hole required in the glass is 1" in diameter

Parts List

- 1. Threaded Anchor
- 2. Attachment Bolts (Customers supply for wood or concrete)
- 3. Standoff (30 or 40mm) with female thread to connect to threaded anchor
- 4. Back Rubber Gasket
- 5. Front Rubber Gasket
- 6. Machine Cap with M10 Bolt




¹ This document includes hyperlinks and is intended to be viewed as a PDF rather than print material

© InlineDesign.com Page 1 of 8



Instructions


1) Begin by bolting down the Threaded Anchor. Mounting hardwares (#2) are NOT supplied by Inline Design. Recommended concrete anchor minimum length 3" (3/8" diameter) and concrete slab minimum PSI 2500. Please refer to concrete anchors manufacturer documents for installation, edge distances and concrete psi ratings.



© InlineDesign.com Page 2 of 8




2) Twist the Standoff to the Threaded Anchor until it's tight.



© InlineDesign.com Page 3 of 8




3) Insert the Back Gasket (#4) to the Standoff, then gently slide the glass with hole into the position. The holes on glass are 1" in diameter.



© InlineDesign.com Page 4 of 8




4) Insert the Front Gasket to the Machine Cap, then twist the assembly into the Standoff. The Machine Cap is designed to have 1 hole to be tightened using the Glass Adapter Tool.



© InlineDesign.com Page 5 of 8






© InlineDesign.com Page 6 of 8




5) Here's the assembly after tightening the Cap.



© InlineDesign.com Page 7 of 8





NOTE:

A small amount of surface corrosion is not uncommon after some exposure to weather or salty conditions; we recommend using our passivation solution or a stainless steel polish to prevent surface corrosion; more information available on our Engineering Specs Page

© InlineDesign.com Page 8 of 8