

Installing Stainless Steel Wall Bracket Square

Overview¹


These are instructions for proper installation of a Stainless Steel Wall Bracket Square, HBWA.008, into sheetrock, wood, or drywall surfaces

This bracket comes with a saddle for both flat and round tubing and a wall bracket screw/hanger bolt

Brackets should be installed with a maximum distance of 5'

Caution:

Wear protective ANSI approved safety glasses, working gloves and breathing mask at all times




Tools Required

- 1) Stud-finder
- 2) Handheld Drill
- 3) 3/16"-1/4" Drill Bit
- 4) 2.5mm, 3.5mm, 5mm Hex Wrench
- 5) M5 Drill and Tap Bit

Bracket Components:

- 1. Hanger Screw
- 2. Wall Flange Plate
- 3. Horizontal Column
- 4. Vertical Column
- 5. Saddle
- 6. Round Tube Adaptor
- 7. M5 Socket Screws
- 8. 2 x M5 Socket Screws
- 9. 2 x M5 Bolts




© inlinedesign.com Page 1 of 2

¹ This document includes hyperlinks and is intended to be viewed as a PDF file rather than print material



Instructions

- 1) Using a stud finder, locate a stud and the vertical point from the nose of your stair (typically 31" vertically depending on your stair angle) and pre drill a hole in the stud using 3/16" drill bit.
- 2) Drive the hanger screw (#1) into the hole and secure the lag end of the stud using a 5mm allen wrench.
- 3) Assemble part #2, #3, and #4 together, then insert the whole assembly into the sleeve. Position the bracket to the desired angle orientation and tighten the hex screw with the 2.5mm wrench.



4) Drill and tap holes into Inline Design steel tubes, refer to these instructions to install Inline Design square or round tubing and additional hardware

Note: If using a round handrail, position the round saddle adapter (part #6) on top of the flat saddle before attaching handrails.

Note: If affixing to a wooden handrail, customers will need to purchase lag screw to replace M5 bolts.

NOTE: A small amount of surface corrosion is not uncommon after some exposure to weather or salty conditions; we recommend using our passivation solution or a stainless steel polish to prevent surface corrosion; more information available on our Engineering Specs Page

© inlinedesign.com Page 2 of 2